



### ***PMM 805 Bren QD mounts installation instructions.***

#### **WARNING!**

Prior to handling any fire arm be sure that the weapon is cleared and is safe to work with, additionally if at any time you do not feel confident in doing the installation of any PMM product PMM recommends you contact a Licensed Gunsmith for assistance.

#### Kit Components:

1x PMM QD Mount

1x .1oz Loctite 242 Blue

1x 1.5mm Allen key

1x PMM Shoulder Mount brackets

3x M2x6 1.5mm bolt

#### **1. Installation of PMM rear QD mount:**

Proper installation of the PMM QD mount requires the QD to be inserted to the sling tang on the side that you choose. ***apply the supplied Loctite 242*** to the 3 M2x6 bolts. Pre-install one of the bolts into the the QD cap and start the threads into the QD. Then install the other two bolts and tighten them down equally using the short side of your 1.5mm wrench. (Hand tighten only)

#### **Image #1.**



**Final Note: Based on intial testing all PMM supplied QD mounts should fit the bren Weapon systems. If for any reason you are having issues with fitment of the mounts into the existing steel sling lugs please feel free to contact me below.**

~Jarod.

E-mail jarod@[parkermountainmachine](mailto:jarod@parkermountainmachine.com).COM

P- (603)664-9606