



## **PMM PRS Ambidextrous QD Mount Installation Instructions.**

### **WARNING!**

Prior to handling any fire arm be sure that the weapon is cleared and is safe to work with, additionally if at any time you do not feel confident in doing the installation of any PMM product, PMM recommends you contact a Licensed Gunsmith for assistance.

#### Kit Components:

2x PMM PRS QD Mount

1x .1oz Loctite 242 Blue

2x M5x 45mm Allen bolts

1x 2.5mm allen wrench

#### **Installation of the PMM PRS QD mount:**

The PMM PRS Ambidextrous QD Sling mounts can be used on either side of the rifle stock in both the factory sling mounts locations. First remove the desired factory sling mount strap bracket and put it to the side.

Take each supplied PMM 3mmx45mm Bolt and place them in the mount with the countersunk holes. **(Image #1)**

Taking the supplied 2nd PMM PRS QD mount, apply a small bit of the supplied loctite 242 to the tip of each bolt prior to threading the bolts into the mount, taking care not to cross thread the bolts. Once the bolts have engaged the mount you may tighten them into position. **(Image #2)**

**Do not over tighten bolts. Snug them down lightly and the loctite 242 will cure in 24hrs and hold them in place.**

**Image #1**



**Image #2**



**Final Note:** Based on initial testing all PMM supplied QD mounts should fit into the PRS 2 Weapon system Stock. If for any reason you are having issues with fitment of the mounts into the existing steel sling lugs please feel free to contact me below.

For questions, visit us online at [www.parkermountainmachine.com](http://www.parkermountainmachine.com) or contact us below at:

[customerservice@parkermountainmachine.com](mailto:customerservice@parkermountainmachine.com)

P: (603)664-9606