



**PMM RUGER PC CARBINE MLOK RAIL installation instructions.**

**WARNING!**

Prior to handling any firearm be sure that the weapon is cleared and is safe to work with, additionally if at any time you do not feel confident in doing the installation of any PMM product PMM recommends you contact a Licensed Gunsmith for assistance.

**Kit Components: 1X PMM RUGER PCC MLOK Rail**

**Installation of the PMM RUGER PCC MLOK Rail** Locate and remove the 4mm allen bolt on the bottom of the stock Ruger hand guard (**see picture 1 for location**) making sure to retain bolt from the stock hand guard as you will need this to install your PMM rail. Remove stock hand guard from the firearm.

Tap the rail into place using a small rubber mallet as it will be a snug fit. Install 4mm allen bolt from stock hand guard on the PMM Ruger PCC MLOK rail by carefully threading the bolt completely through the rail. The bolt will now stay with the rail as it is retained on the new PMM rail due to the threads.

Place PMM Ruger PCC MLOK rail in the same location as the stock hand guard and tighten the single 4mm allen bolt making sure not to apply too much torque (**see picture 2**)

Picture 1

Picture 2

