



PMM SCAR FRONT QD Mount Installation Instructions.

WARNING!

Prior to handling any fire arm be sure that the weapon is cleared and is safe to work with, additionally if at any time you do not feel confident in doing the installation of any PMM product PMM recommends you contact a Licensed Gunsmith for assistance.

Kit Components:

1x Front PMM QD Mount.

1x .1oz Loctite 242 Blue

1x PMM Shoulder Mount brackets

1x 3mm-8mm T10 Torx Bolt

2. Installation of the PMM Front QD mount:

Taking the PMM QD front mount place it so it sits inside the front sling mount , **apply the supplied Loctite 242** to the 3mm bolt then using the PMM shoulder mount bracket with a T10 Torx Wrench lightly begin to tighten the bolt into position, once again making sure your threads and the machined surfaces are lining up prior to tightening them down snug as seen in **Image #2**

Image# 2.



Final Note: Based on initial testing all PMM supplied QD mounts should fit both the 16 and 17 Weapon systems. If for any reason you are having issues with fitment of the mounts into the existing steel sling lugs please feel free to contact me below.

~Jarod.

E-mail jarod@parkermountainmachine.com

P- (603)664-9606