



PMM SCAR Rear QD mounts installation instructions.

WARNING!

Prior to handling any fire arm be sure that the weapon is cleared and is safe to work with, additionally if at any time you do not feel confident in doing the installation of any PMM product PMM recommends you contact a Licensed Gunsmith for assistance.

Kit Components:

1x Rear PMM QD Mount

1x .1oz Loctite 242 Blue

2x PMM Shoulder Mount brackets

2x m3x8mm T10 Torx bolts

1. Installation of PMM rear QD mount:

Proper installation of the PMM rear QD mount requires the Removal of the trigger group and rear stock assembly of the rifle, please refer to your user manual to do so .With the stock removed take the supplied PMM rear QD mount and place it into the corresponding rear sling mount holes. PMM recomends you ***apply the supplied Loctite 242*** to the torx bolts then take the supplied shoulder mount brackets with a T10 torx bolt and torx wrench then lightly begin to tighten the bolts into position, making sure your threads and the machined surfaces are lining up prior to tightening them down snug as seen in **Image #1**.

Image #1.



Final Note: Based on intial testing all PMM supplied QD mounts should fit both the 16 and 17 Weapon systems. If for any reason you are having issues with fittment of the mounts into the existing steel sling lugs please feel free to contact me below.

~Jarod.

E-mail jarod@parkermountainmachine.COM

P- (603)664-9606