



PMM ROMEO 1 COVER PLATE

WARNING!

Prior to handling any fire arm be sure that the weapon is cleared and is safe to work with, additionally if at any time you do not feel confident in doing the installation of any PMM product, PMM recommends you contact a licensed gunsmith for assistance.

Kit Components:

1x COVER PLATE

4X SHIM SPACERS

Installation of the PMM ROMEO 1 COVER PLATE:

Remove the factory mounted Romeo 1 optic (retain the mounting bolts). Place the cover plate in the recess where the optic was, checking for proper fitment. Put (2) shim spacers on each of the bolts used to mount the optic and thread them into the slide, capturing the cover plate. Do not over tighten! Hand snug will be sufficient and no loctite is needed but may be applied if you do not plan on taking the cover plate off.

If for any reason you are having issues with fitment of the cover plate, please feel free to contact me below.

E-mail me at jarod@parkermountainmachine.com or call (603)664-9606